Soft Flex.

Beading Wire Color Chart



Available in .019" only unless noted.





Available in .014", .019" & .024".





Available in all diameters unless noted.





Available in .014", .019" & .024".





Available in .014" & .019".





Available in .010", .014" & .019" unless noted.

Econoflex™ Wire						
Midnight Black						
Steel Blue						
Autumn Brown						
Spring Green						
Plum						
Cinnamon Red						
Steel Grey						
Snow White (.014" & .019" only)						

Wire Diameter Chart

BRAND	DIAMETER	STRANDS	TEST STRENGTH	BASIC USAGE	CRIMP TO USE
Soft Touch™ Black, White and Safin Silver Color	.010" (.25mm) Very Fine	7	5 lbs.	Ideal for embellishing, weaving, crocheting and stringing very small beads.	lx1mm
Soft Flex® Soft Touch™ Metallics™ Extreme™ Pro Econoflex™	.014" (.36mm) Fine	21 21 21 19 49	10 lbs. 10 lbs. 10 lbs. 10 lbs. 21 lbs.	Ideal for soft materials, seed beads and fresh water pearls.	2x2mm
Soft Flex® Soft Touch™ Metallics™ Extreme™ Pro Econoflex™	.019" (.48mm) Medium	49 49 49 19 49	26 lbs. 26 lbs. 26 lbs. 15 lbs. 26 lbs.	Ideal all purpose wire. Great with glass, mineral and metal beads.	2x2mm
Soft Flex® Soft Touch™ Metallics™ Extreme™	.024" (.61mm) Heavy	49 49 49 19	40 lbs. 40 lbs. 40 lbs. 20 lbs.	Ideal for abrasive materials, large stones, lampwork and bracelets.	2x2mm or 2x3mm
Econoflex™	.010" (.25mm) .014" (.36mm) .019" (.48mm)	7 7 7	10 lbs. 15 lbs. 20 lbs.	Ideal for crafts. Beaded lampshades, beaded curtains and craft jewelry.	1x1mm 2x2mm 2x2mm

Soft Flex.

Orimping with Micro, Regular or Wighty Orimping Pliers




Step 1
String a crimp tube and a clasp onto the wire. String the wire back through the crimp tube.
Straighten the wires inside the crimp tube so that they lie side by side.



Step 2
Using the "crimper,"
gently compress
the crimp tube,
creating a divot.



Step 3
Using the "rounder,"
gently compress the
crimp tube. Turn and
repeat 3 times until
it creates a round
shape and equalizes
the pressure. Cut off
the excess wire at the
base of the crimp.



Crimping with Magical Crimping Pliers



Step 1
String a crimp tube.
If attaching a clasp
or ear wire, make
sure that the wires
lay side by side.



Step 2
Place the crimp
tube inside the
groove of the
Magical Crimping
Pliers and squeeze.



Step 3
The pliers will pinch the four corners of the crimp tube and look like a square.



Step 4

Turn the crimp tube on its side in the Magical Crimping Pliers, making sure the top of the square is up and squeeze.



Step 5
Rotate and squeeze
a few more times.
The crimp should
tighten down on the
wire and look like
a round bead.





www.facebook.com/SoftFlexWire



Subscribe to our YouTube Channel for regular video tutorials!

www.youtube.com/c/SoftFlexCompany

